
LH SWITCH
22
MAIN SWITCH
23
BLINKER
24
HORN
25
SIDESTAND SENSOR
26
CLUTCH
27
NEUTRAL
28
WTS
29
TMAP SENSOR
30
TPS SENSOR
31
FRONT STOP
32
REAR STOP
33
Front SPEED
34
Rear SPEED
35
RH TURN
36
TAIL LAMP
37
LH TURN
38
39
ABS SWITCH
40
ABS ECU
41
K LINE
Diode1
Diode2
21
DASHBOARD
20
RH TURN
19
FRONT LAMP
18
LH TURN
1
ENGINE ECU
2
INTERFACE
17
PURGE VALVE
16
02 SENSOR HEATER
15
COIL
14
INJECTOR
13
IDLE VALVE
12
FUEL PUMP
11
FUEL LEVEL
10
P.RELAY
9
RH SWITCH
8
REGULATOR
7
ACG
6
FUSES
5
BATTERY
4
START RELAY
3
START MOTOR